

Redis 安装

1. 下载软件包

找到redis官网,下载最新软件包Redis官网下载



- 2. 安装redis 根据官方文档<u>重新开始快速 重新 (redis.io)</u>
 - 1. 将下载的Redis安装包拖入虚拟机中



2. 解压安装redis

1 [root@localhost ~]# tar -zxvf redis-6.2.6.tar.gz

```
스미(F) 제44(E) 모(V) 1X까(Y) 전세(F) 105/(F)
[root®localhost ~]# tar -zxvf redis-6.2.6.tar.gz
redis-6.2.6/
redis-6.2.6/.github/
redis-6.2.6/.github/ISSUE_TEMPLATE/
redis-6.2.6/.github/ISSUE_TEMPLATE/bug_report.md
redis-6.2.6/.github/ISSUE_TEMPLATE/crash_report.md
redis-6.2.6/.github/ISSUE_TEMPLATE/feature_request.md
redis-6.2.6/.github/ISSUE_TEMPLATE/other_stuff.md
redis-6.2.6/.github/ISSUE_TEMPLATE/question.md
redis-6.2.6/.github/workflows/
redis-6.2.6/.github/workflows/ci.yml
redis-6.2.6/.github/workflows/daily.yml
redis-6.2.6/.gitignore
redis-6.2.6/00-RELEASENOTES
redis-6.2.6/BUGS
redis-6.2.6/CONDUCT
redis-6.2.6/CONTRIBUTING redis-6.2.6/COPYING
redis-6.2.6/INSTALL
redis-6.2.6/MANIFESTO
redis-6.2.6/Makefile
redis-6.2.6/README.md
redis-6.2.6/TLS.md
  1 [root@localhost ~]# ls
  2
       anaconda-ks.cfg
                                      redis-6.2.6.tar.gz
                                                                   模板 文档
                                                                                  桌面
  3
       initial-setup-ks.cfg redis-stable.tar.gz 视频
                                                                         下载
  4
       redis-6.2.6
                                      公共
                                                                  图片 音乐
  5
       [root@localhost ~]# cd redis-6.2.6/
       [root@localhost redis-6.2.6]# make
  6
                                  root@localhost:~/redis-6.2.6
                                                                                        п
文件(F) 编辑(E) 查看(V) 搜索(S) 终端(T) 帮助(H)
[root@localhost ~]# ls_
                          redis-6.
.
anaconda-ks.cfg
initial-setup-ks.cfg
 root®localhost ~] # cd redis-6.2.6/
root@localhost redis-6.2.6|# make
```

3. 将命令创建软链接

```
[root@localhost redis-6.2.6]# sudo cp src/redis-server
/usr/local/bin/
[root@localhost redis-6.2.6]# sudo cp src/redis-cli
/usr/local/bin/
```

4. 启动redis

1 root@localhost redis-6.2.6]# redis-server

```
lbUbl:C UI NOV 2021 15:33:31.456 # Redis Version⇒5.2.6, bits⇒4, commit⇒00000000, modified⇒0, pid⇒16051, just started 16051:C 01 Nov 2021 15:33:31.456 # Warning: no config file specified, using the default config. In order to specify a config file use redis-server /path/to/redis.conf 16051:M 01 Nov 2021 15:33:31.457 * Increased maximum number of open files to 10032 (it was originally se
t to 1024).
|6051:M 01 Nov 2021 15:33:31.457 * monotonic clock: POSIX clock_gettime
                                                         Redis 6.2.6 (00000000/0) 64 bit
                       :.//
                                                         Running in standalone mode
                                                         Port: 6379
PID: 16051
                                                                 https://redis.io
 .6051: M 01 Nov 2021 15:33:31.458 # WARNING: The TCP backlog setting of 511 cannot be enforced because /p
```

roc/sys/net/core/somaxconn is set to the lower value of 128.
16051: M 01 Nov 2021 15:33:31.458 # Server initialized
16051: M 01 Nov 2021 15:33:31.458 # WARNING overcommit_memory is set to 0! Background save may fail under low memory condition. To fix this issue add 'vm.overcommit_memory = 1' to /etc/sysctl.conf and then reb oot or run the command 'sysctl vm.overcommit_memory=! for this to take effect.
16051: M 01 Nov 2021 15:33:31.459 * Ready to accept connections

错误1

```
16164:M 01 Nov 2021 15:38:11.205 # WARNING: The TCP
  backlog setting of 511 cannot be enforced because
  /proc/sys/net/core/somaxconn is set to the lower value of
  16164:M 01 Nov 2021 15:38:11.205 # Server initialized
  16164:M 01 Nov 2021 15:38:11.205 * Loading RDB produced by
3
  version 6.2.6
  16164:M 01 Nov 2021 15:38:11.205 * RDB age 164 seconds
  16164:M 01 Nov 2021 15:38:11.205 * RDB memory usage when
  created 0.77 Mb
  16164:M 01 Nov 2021 15:38:11.205 # Done loading RDB, keys
  loaded: 0, keys expired: 0.
  16164:M 01 Nov 2021 15:38:11.205 * DB loaded from disk:
   0.000 seconds
 16164:M 01 Nov 2021 15:38:11.205 * Ready to accept
   connections
```

```
16051:M 01 Nov 2021 15:33:31.458#警告: 无法强制执行TCP积压设
   置511,因为/proc/sys/net/core/somaxconn被设置为较低的值128。
2
3
   16051:M 01 Nov 2021 15:33:31.458#服务器已初始化
4
   16051:M 01 Nov 2021 15:33:31.458 35;警告超限#内存设置为0! 在
   内存不足的情况下,后台保存可能会失败。要解决此问题,请
   将"vm.overmit_memory=1"添加到/etc/sysctl.conf,然后重新启动或
   运行命令"sysctl vm.overmit_memory=1",使其生效。
6
7
   16051:M 01 Nov 2021 15:33:31.459*准备接受连接
8
9
   ^C16051:信号处理程序(1635752127)收到SIGINT计划关闭。。。
10
11
   16051:M 01 Nov 2021 15:35:27.944 35;用户请求关机。。。
12
   16051:M 01 Nov 2021 15:35:27.944*退出前保存最终RDB快照。
13
14
   16051:M 01 Nov 2021 15:35:27.945*DB保存在磁盘上
15
16
```

```
17 | 16051:M 01 Nov 2021 15:35:27.945#Redis现在准备退出,再见。。。
```

出现内存设置问题,根据redis报错提示

将参数"vm.overmit_memory=1"添加到/etc/sysctl.conf,然后重新启动或运行命令"sysctl vm.overmit_memory=1",使其生效。

5. 将redis后台启动

```
1 [root@localhost redis-6.2.6]# redis-server &
```

6. 测试redis连接

```
1 [root@localhost redis-6.2.6]# redis-cli ping
2 PONG
```

```
[root@localhost redis-6.2.6]# redis-cli ping
PONG
[root@localhost redis-6.2.6]#
```

3. 配置redis的配置文件

1. 关闭redis

```
1 [root@localhost redis-6.2.6]# redis-cli shutdown
2 16278:M 01 Nov 2021 15:49:39.438 # User requested shutdown...
3 16278:M 01 Nov 2021 15:49:39.438 * Saving the final RDB snapshot before exiting.
4 16278:M 01 Nov 2021 15:49:39.708 * DB saved on disk
5 16278:M 01 Nov 2021 15:49:39.708 # Redis is now ready to exit, bye bye...
6 [1]+ 完成 redis-server
```

```
[root®localhost redis-6.2.6] # redis-cli shutdown
16278:M 01 Nov 2021 15:49:39.438 # User requested shutdown...
16278:M 01 Nov 2021 15:49:39.438 * Saving the final RDB snapshot before exiting.
16278:M 01 Nov 2021 15:49:39.708 * DB saved on disk
16278:M 01 Nov 2021 15:49:39.708 # Redis is now ready to exit, bye bye...
[1] + 完成

[1] + 完成
```

2. 创建存储 Redis 配置文件和数据的目录

```
1  [root@localhost ~]# cd
2  [root@localhost ~]# sudo mkdir /etc/redis
3  [root@localhost ~]# sudo mkdir /var/redis
```

3. 将在utils目录下的Redis发行版中找到的init脚本复制到/etc/init.d中。我们建议使用运行此Redis实例的端口名来调用它

```
[root@localhost ~]# cd redis-6.2.6/
[root@localhost redis-6.2.6]# sudo cp utils/redis_init_script
/etc/init.d/redis_6379
```

4. 编辑初始化脚本

1 sudo vim /etc/init.d/redis_6379

```
#!/bin/sh

# Simple Redis init.d script conceived to work on Linux systems
# as it does use of the /proc filesystem.

### BEGIN INIT INFO

# Provides: redis_6379

# Default.Start: 2 3 4 5

# Default.Start: 0 1 6

# Short-Description: Redis data structure server

# Description: Redis data structure server.

# Description: Redis data structure server. See https://redis.io

### END INIT INFO

##EDISPORT=637

EXEC=/usr/local/bin/redis-server

CLIEXEC=/usr/local/bin/redis-cli

# PIDFILE=/var/run/redis_${REDISPORT}.pid

CONF="/etc/redis/${REDISPORT}.conf"
```

端口号默认为6379不用修改

5. 使用端口号作为名称,将Redis发行版根目录中的模板配置文件复制到/etc/Redis/中

```
1 | sudo cp redis.conf /etc/redis/6379.conf
```

6. 在/var/redis内创建一个目录,该目录将用作此redis实例的数据和工作目录

```
1 | sudo mkdir /var/redis/6379
```

- 7. 编辑配置文件,确保执行以下更改:
 - 将daemonize设置为yes (默认情况下设置为no)
 - 将pidfile设置为 (根据需要修改端口) /var/run/redis_6379.pid`
 - 相应地更改端口。在我们的示例中,不需要它,因为默认端口已经是6379
 - 设置您的首选日志级别。
 - 将日志文件设置为 /var/log/redis_6379.log
 - 将dir设置为/var/redis/6379 (非常重要的一步!)

Edit the configuration file, making sure to perform the following changes:

- Set **daemonize** to yes (by default it is set to no).
- Set the pidfile to (modify the port if needed). /var/run/redis_6379.pid
- Change the **port** accordingly. In our example it is not needed as the default port is already 6379.
- Set your preferred loglevel.
- Set the logfile to /var/log/redis_6379.log
- Set the dir to /var/redis/6379 (very important step!)
- 1. 进入配置文件
- 1 [root@localhost redis-6.2.6]# vim /etc/redis/6379.conf
 - 8. 修改配置文件
 - 9. 使用搜索,搜索需要更改的配置项

By default Redis does not run as a daemon. Use 'yes' if you need it.
Note that Redis will write a pid file in /var/run/redis.pid when daemonized.
When Redis is supervised by upstart or systemd, this parameter has no impact.
daemonize yes

- 1 257 daemonize yes #257行的此配置项 更改为yes
- 10. 修改pidfile文件位置
 - 1 289 pidfile /var/run/redis_6379.pid
- 11. 修改日志级别
 - 1 297 loglevel notice
- 12. 修改日志文件位置
 - 1 | 302 logfile "/var/log/redis_6379.log"
- 13. 修改目录位置
 - 1 | 454 dir /var/redis/6379
- 14. 修改默认IP
 - 1 75 bind 192.168.117.22
- 8. 使用以下命令将新的Redis init脚本添加到所有默认运行级别(设置开机自启动)
 - 1 [root@localhost redis-6.2.6]# systemctl enable redis_6379
 - redis_6379.service is not a native service, redirecting to
 /sbin/chkconfig.
 - 3 Executing /sbin/chkconfig redis_6379 on
- 9. 启动redis
 - [root@localhost redis-6.2.6]# sudo /etc/init.d/redis_6379
 start
 - 2 | Starting Redis server...
- 10. 关闭,开启,连接数据库

```
1  [root@localhost redis-6.2.6]# redis-cli -h 192.168.117.22
    shutdown
2
3  [root@localhost redis-6.2.6]# sudo /etc/init.d/redis_6379
    start
4  Starting Redis server...
5
6  [root@localhost redis-6.2.6]# redis-cli -h 192.168.117.22 -p
6379
7  192.168.117.22:6379>
```

11. 测试方法

确保一切按预期进行:

- 尝试使用redis cli ping您的实例
- 使用redis cli save执行测试保存,并检查转储文件是否正确存储 到/var/redis/6379/(您应该找到一个名为dump.rdb的文件).
- 检查您的Redis实例是否正确地登录到日志文件中.
- 如果这是一台新机器,您可以毫无问题地试用它,请确保在重新启动后, 一切仍然正常。